

## ШТУЦЕРА-ПЕРЕХОДНИКИ, СAE С НАРУЖНОЙ РЕЗЬБОЙ x NPT С ВНУТРЕННЕЙ РЕЗЬБОЙ

U3-04A	1/4"	MFL	x	1/8"	FPT
U3-04B	1/4"	MFL	x	1/4"	FPT
U3-04C	1/4"	MFL	x	3/8"	FPT
U3-05A	5/16"	MFL	x	1/8"	FPT
U3-05B	5/16"	MFL	x	1/4"	FPT
U3-06A	3/8"	MFL	x	1/8"	FPT
U3-06B	3/8"	MFL	x	1/4"	FPT
U3-06C	3/8"	MFL	x	3/8"	FPT
U3-06D	3/8"	MFL	x	1/2"	FPT
U3-08B	1/2"	MFL	x	1/4"	FPT
U3-08C	1/2"	MFL	x	3/8"	FPT
U3-08D	1/2"	MFL	x	1/2"	FPT
U3-10C	5/8"	MFL	x	3/8"	FPT
U3-10D	5/8"	MFL	x	1/2"	FPT
U3-10E	5/8"	MFL	x	3/4"	FPT

