


ПЕРЕХОДНИКИ

Каталог №	Размер		2
	1	x	
801105	1/4"	x	3/8"
801106		x	1/4"
801107		x	1/8"
801109	5/16"	x	3/8"
801110		x	1/4"
801113	3/8"	x	1/2"
801114		x	3/8"
801115		x	1/4"
801116		x	1/8"
801123	1/2"	x	3/4"
801124		x	1/2"
801125		x	3/8"
801126		x	1/4"
801129	5/8"	x	1"
801130		x	3/4"
801131		x	1/2"
801132		x	3/8"
801133		x	1/4"
801138	3/4"	x	3/4"
801139		x	1/2"
801145	7/8"	x	1"
801146		x	3/4"
801147		x	1/2"
801161	1 1/8"	x	1 1/2"
801162		x	1 1/4"
801163		x	1"
801164		x	3/4"
801165		x	1/2"
801170	1 3/8"	x	1 1/2"
801171		x	1 1/4"
801172		x	1"
801173		x	3/4"
801178	1 5/8"	x	2"
801179		x	1 1/2"
801180		x	1 1/4"
801181		x	1"
801187	2 1/8"	x	2"
801188		x	1 1/2"
801189		x	1 1/4"
801196	2 5/8"	x	2 1/2"
801197		x	2"
801198		x	1 1/2"
801199	3 1/8"	x	3"
801150	4 1/8"	x	4"



Тип 204
Соединение С x МРТ

размеры и допуски в соответствии с ASME B16.22