

UNION VALVES

MV-1818	1/4" MFL (+ core & cap with core-wrench remover) x 1/8" MPT.
MV-1818C	1/4" MFL (+ core & standard cap) x 1/8" MPT
MV-1414	1/4" MFL (+ core & cap with core-wrench remover) x 1/4" MPT.
MV-1414C	1/4" MFL (+ core & standard cap) x 1/4" MPT
MV-1441	1/4" MFL with inside core (1) . x 1/4" MFL with nut for connecting flared tube (2) . Central hex pad for back wrench.
MV-8725	1/4" FFL fixed with a gasket. x 1/4" MFL with inside core (hex). TWO hex mounting pads for wrench and back wrench. The valve body is stationary. When threads of existing system fittings are stripped and a new core won't go in, use this. It has a core and NO depressor tip.
MV-1454	1/4" MFL (+ core) x 1/4" FFL (swivel nut + depressor).

