

OIL RECEIVERS - VERTICAL

- It is recommended to keep an oil reserve to avoid any oil foaming in the compressor crankcases.
- Oil remains in the receiver enabling the oil level control to operate properly and ensure a correct oil distribution towards each compressor crankcase.
- Supplied with 2 rotaloc valves with backseating that fit the top and bottom receiver connections. Each rotaloc valve provides a regular $\frac{3}{8}$ " male flare SAE connection and an extra $\frac{1}{4}$ " male flare SAE port (with cap) to allow filling or emptying of oil from the receiver.
- Oil receivers have 2 sight glasses with incorporated ball.
- Extra $\frac{3}{8}$ " male flare SAE connection on top for check-valve connection.

PART NUMBER	LITRES	A	B	C	D	E
ORV-08	8	160	160	360	152	480
ORV-12	12	236	236	532	152	710
ORV-15	15	300	300	575	152	900

