Tel: +32 3 766 02 02 Fax: +32 3 766 10 67



## COUDES à 45°

CODE	Connexions d	± Dimensions (mm) d a Z		
	u	u	а	2
5041-06	06 mm	6	9	3
5041-08	08 mm	8	11	4
5041-10	10 mm	10	12	4
5041-12	12 mm	12	14	5
5041-14	14 mm	14	16,5	5,5
5041-15	15 mm	15	17	6
5041-16	16 mm	16	18	7
5041-18	18 mm	18	20	7
5041-22	22 mm	22	25	9
5041-28	28 mm	28	29	10
5041-35	35 mm	35	37	14
5041-42	42 mm	42	42	15
5041-54	54 mm	54	52	20
5041-64	64 mm	64	62	27
5041-67	67 mm	67	65	28,5
5041-76	76 mm	76	68	32
5041-80	80 mm	80	83	48
5041-89	89 mm	89	78	37,5
5041-108	108 mm	108	110	60
5041-133	133 mm	133	280	235
5041-159	159 mm	159	335	290

