

ПЕРЕХОДНЫЕ МУФТЫ, МУФТОВАЯ СВАРКА

DMF-S-02	1/4" SW
DMF-S-03	3/8" SW
DMF-S-04	1/2" SW
DMF-S-06	3/4" SW
DMF-S-08	1" SW
DMF-S-10	1 1/4" SW
DMF-S-12	1 1/2" SW
DMF-S-16	2" SW
DMF-S-20	2 1/2" SW
DMF-S-24	3" SW

