

Tel : +32 3 766 02 02
Fax: +32 3 766 10 67



ПЕРЕХОДНЫЕ МУФТЫ, 2 x МУФТОВАЯ СВАРКА

MFF-S-02	1/4" SW
MFF-S-03	3/8" SW
MFF-S-04	1/2" SW
MFF-S-06	3/4" SW
MFF-S-08	1" SW
MFF-S-10	1 1/4" SW
MFF-S-12	1 1/2" SW
MFF-S-16	2" SW
MFF-S-20	2 1/2" SW
MFF-S-24	3" SW
MFF-S-32	4" SW

